


# Optional Parts


## Motor (with Brake) junction cables (Robotop®, 600V • DP)

fig 4-1 **MFMCB0 \*\* 0GET** (Brake cable)




L (m)	Part No.
3	MFMCB0030GET
5	MFMCB0050GET
10	MFMCB0100GET
20	MFMCB0200GET

fig 4-2 **MFMCA0 \*\* 2FCC**




L (m)	Part No.
3	MFMCA0032FCC
5	MFMCA0052FCC
10	MFMCA0102FCC
20	MFMCA0202FCT

fig 4-3 **MFMCA0 \*\* 2FCT**



L (m)	Part No.
3	MFMCA0032FCT
5	MFMCA0052FCT
10	MFMCA0102FCT
20	MFMCA0202FCT

fig 4-4 **MFMCA0 \*\* 3FCT**



L (m)	Part No.
3	MFMCA0033FCT
5	MFMCA0053FCT
10	MFMCA0103FCT
20	MFMCA0203FCT

## Communication Cables (for connection to personal computer)

1) Part No. DV0P1960 (for DOS/V)

